ALPHASET

Test your heatpress!

Heat-measurement-strips ZU602 This is how it works:

- Heat the press to 150 degrees and set it to medium pressure.
- Wait 5 minutes after the temperature has been reached, then pre-press for 90 seconds.
- Stick the measuring strip in the center of the bottom plate and then press for 30 seconds. The discoloration of the test strip indicates whether the press
- temperature matches the display on the transfer press.

You can now test with the same measuring strip at a higher temperature, e.g., 160 degrees, etc.

It is possible that the heating plate heats unevenly and has cold spots. In this case, test with several test strips at different positions.

If you want to take measurements frequently, we recommend the OTZ03 temperature measuring device. Translated with DeepL.com (free version)



shop.alphaset.com